



| FIG | .3 | | | | | |
|----------------------|----------------------|-----------------------------|-----------------------------|-----------------------------|-----------------------------|------------------------------|
| | Repro | duction S | top Reprod | duction St | top St | top |
| Mode | 2nd stop mode 144 | Reproduction mode 142 | | Reproduction mode 142 | | 2nd stop mode 144 |
| | | 0 | | | | |
| Video output | | Still picture signal 131 | Still picture signal 131 | Still picture signal 131 | Still picture signal 131 | External video signal 125 |
| | | | | | | |
| Audio output | | Audio signal 130 | Mute | Audio signal 130 | Mute | External audio signal 124 |
| Volume level ♣ | | D1 | | D1 | | A1 |
| | | DI | | DI | | |
| | t | 1 1 | :2 t | :3 t | :4 t | .5 Time |

FIG.4 Reproduction Stop Reproduction Stop Reproduction 1st stop 2nd stop Reproduction 1st stop 2nd stop Mode mode 145 mode 142 mode 145 mode 144 mode 144 mode 142 Still picture Video signal Still picture External video signal 131 129A,129B signal 131 signal 125 Video signal Video 129A,129B output External audio Audio signal 128A,128B Audio signal Audio Mute Mute signal 124 128A,128B output Volume level B1 or Α1 B1 or C1 C1 t10 Time t6 t7 t8 t9

FIG.5

| | Reco | rding St | op Reprod | Juction St | op | _ |
|-----------------|----------------------|------------------------------|------------------------------|-----------------------|------------------------------|--------|
| Mode | 2nd stop mode 144 | Recording mode 143 | Stop mode 141 | Reproduction mode 142 | Stop mode 141 | - |
| | | | | | | _ |
| Video output | | External video signal 125 | External video signal 125 | Video signal 127 | External video signal 125 | _ |
| • | | | | | | |
| Audio output | | External audio signal 124 | External audio signal 124 | | External audio signal 124 | |
| · v | olume | | | Ì | | |
| | level | A1 | A1 | A1 | A1 | _ |
| | | | | | ! ! ! | |
| | L | t11 | t12 | t13 | 114 | Time |